

## Hardware kit



Hardware kit consisting of 68 S/S screws. The original black screws on your motorcycle fairing lose a little bit of crispness each time they are screwed in or out. These stainless and polished screws look great and remain that way for years. Complete set with all screws needed and fitting guidelines.

10x M6 screws and 58x M5 screws  
= 10x 0421006 and 58x 0421005

**Art-Nr.: 70035**

**35,90 EUR**

for K1200LT

**Art-Nr.: 0421005**

**0,20 EUR**

Transparent Polyamid Shim (1 piece)

external diameter 9,8mm; bore diameter 5,3mm; thickness 1mm

**Art-Nr.: 0421006**

**0,20 EUR**

Transparent Polyamid Shim (1 piece)

external diameter 12mm; bore diameter 6,4mm; thickness 1,6mm

**Art-Nr.: 1506-466**

**0,20 EUR**

Black Polyamid Shim (1 piece)

external diameter 9,8mm; bore diameter 5,3mm; thickness 1mm