

SP Connect Mirror Mount



The SP Connect Mirror Mount is the perfect way to attach your smartphone to the motorcycle in a matter of seconds, flexibly and intuitively. The Mirror Mount can, for example, be mounted on mirror tubes and on all of our GPS mounts with a tube mount and offers a stable 360° adjustment option in 6° increments in order to be able to position the smartphone optimally. The smartphone can be fixed in both portrait and landscape format.

Install Instruction SP Connect Mirror Mount

Note: If a smartphone with a mechanical image stabilizer is attached to the Mirror Mount, we recommend using an additional vibration-dampening module (item 688066) to best prevent damage to the smartphone's camera that can be caused by vibrations from motorcycle engines. The Anti Vibration Module reduces vibrations by up to 60%. The head of the Mirror Mount is easily interchangeable with the anti-vibration module, which allows the smartphone to be fixed directly on the vibration-dampening module with a 90° clockwise rotation. However, if problems occur, the Mirror Mount should no longer be used in combination with this smartphone!

Install Instruction SP Anti Vibration Module

Either the SP Universal Phone Case, the SP Universal Interface or the SP Universal Phone Clamp can be used to attach the smartphone to the Mirror Mount.

The SP Universal Phone Case 688060921 offers space for smartphones with a maximum size of approx. 153 x 70 mm. The SP Universal Phone Case protects the phone from rain, sweat, mud and dust, offers good touchscreen usability and has a camera window and a protective fleece insert. The smartphone is pushed into the case, the opening is rolled up and then fixed with the Velcro surface.

Note: Wireless charging is not guaranteed when using this product.

Install Instruction SP Universal Phone Case

The SP Universal Interface makes any phone case or other device compatible with the SPC+ system. This is a

flat and robust pad that is equipped with a 3M adhesive film for flexible use. For installation, the protective film of the adhesive pad is removed and pressed onto the back of the smartphone case or other device. For best results, it should be positioned as centrally as possible.

Note: Wireless charging is not guaranteed when using this product.

Attention: The use of the SP Universal Interface is at your own risk! Observe the information in the installation instructions!

Install Instruction SP Universal Interface

The SP Universal Phone Clamp SPC+ fits smartphones with a maximum thickness of 12mm and a width between 58 and 85mm. The smartphone clamp mount has a simple and rock-solid locking system: simply pull out the crown, screw it tight and fix the crown by pushing it in. The clamp bracket can be adjusted without tools.

Note: Wireless charging is not guaranteed when using this product.

Install Instruction SP Universal Phone Clamp

Art-Nr.: 688009	29,90 EUR
------------------------	------------------

SP Connect Mirror Mount

Art-Nr.: 688066	29,90 EUR
------------------------	------------------

SP Anti Vibration Module SPC+

Art-Nr.: 688060921	29,90 EUR
---------------------------	------------------

SP Universal Phone Case small SPC+

For smartphones with a maximum size of approx. 153 x 70 mm

Art-Nr.: 688061	22,40 EUR
------------------------	------------------

SP Universal Interface SPC+

Art-Nr.: 688063	29,90 EUR
------------------------	------------------

SP Universal Phone Clamp SPC+

Additional pictures:

