

Loop Antenna



The loop antenna of the electronic immobilizer may fail. As a result, the motor does not get the necessary signal to trigger a start operation. The loop antenna should be included in the baggage of every BMW driver. Very easy to assemble:

1. Deduct the cable plug from the old antenna.
2. Connect new antenna.
3. Hold spare key to the ring antenna.
4. Start with original key.

BMW K72 F650GS (2008-) & F800GS

BMW K40 K1200S & K1300S

BMW K43 K1200R, K1200R Sport & K1300R

BMW K44 K1200GT (2006-) & K1300GT

BMW K25 R1200GS 2004-2012

BMW K25 R1200GS Adventure 2005-2013

BMW K25 HP2 Enduro

BMW K25 HP2 Megamoto

BMW K27 R1200R 2006-2014

BMW K28 R1200ST

BMW K26 R1200RT 2006-2013

BMW K29 R1200S & HP2 Sport

BMW K21 RnineT (2013-2016)

BMW K42 HP4

BMW K46 S1000RR (-2014)

BMW K48 K1600GT (-2016) & K1600GTL (-2016)

BMW K70 F700GS

BMW K71 F800GT, F800S & F800ST

BMW K75 F800GS Adventure

BMW K73 F800R

Attention: Once the parts have been installed, they cannot be returned!

Loop Antenna